MONTECH


MKey PRO Update Bluetooth5.2 Firmware SOP

English	P.2
繁體中文	P.6

MKey PRO

English

Step 1: Open MONTECH Firmware Updater




Step 2: Get Ready for MKey PRO



Set the switch to USB mode.
Connect the cable between MKey PRO and the device.

Step 3: Get Ready for MONTECH Firmware Updater



1.
Click “Browse…”.

2.
Find out the kfw document which is provided by MONTECH.

3.
Click “Upgrade” and wait for the process to complete.

You will see “Update completed, please unpair and re-pair The device if Bluetooth is supported”.


4.
Click “Get Version”.

You will see “Device firmware version: 0.2.4”.

MKey PRO

繁體中文

第一步：開啟MONTECH Firmware Updater




第二步：準備好MKey PRO



將模式開關切換至USB模式。
用線材連接MKey PRO和設備。

第三步：準備好MONTECH Firmware Updater



1.
點選「Browse...」。

2.
找到MONTECH提供的kfw檔文件。

3.
點選「Upgrade」並等待完成。

完成後會顯示
「 Update completed, please unpair and re-pair the device if Bluetooth is supported 」。

4.
點選「Get Version」。

完成後會顯示「Device firmware version: 0.2.4」。